


Create Motor Sim



Working steps

1. Create Motor Sim
2. Sending telemetry data from Motor device Sim to Azure IoT Hub
3. Send data to Azure Stream Analytics
4. Sink event to BI
5. Create data visualization in Microsoft Power BI



Question

Is the motor run normally?



Is the motor speed right?

Is the motor need maintenance?

Application

Preventive maintenance

Motor's anatomy



Context

- The dataset comprises several sensor data collected from a permanent magnet synchronous motor (PMSM) deployed on a test bench.
- The PMSM represents a german OEM's prototype model.
- Test bench measurements were collected by the LEA department at Paderborn University. This dataset is mildly anonymized.

Content

- All recordings are sampled at 2 Hz.
- The dataset consists of multiple measurement sessions, which can be distinguished from each other by column "profile_id".
- A measurement session can be between one and six hours long.
- The motor is excited by hand-designed driving cycles denoting a reference motor speed and a reference torque.
- Currents in d/q-coordinates (columns "i_d" and "i_q") and voltages in d/q-coordinates (columns "u_d" and "u_q") are a result of a

standard control strategy trying to follow the reference speed and torque.

- Columns "motor_speed" and "torque" are the resulting quantities achieved by that strategy, derived from set currents and voltages.
- Most driving cycles denote random walks in the speed-torque-plane in order to imitate real world driving cycles to a more accurate degree than constant excitations and ramp-ups and -downs would.

Motor's sensors data

ambient	coolant	u_d	u_q	motor_speed	torque	i_d	i_q	pm	stator_yoke	stator_tooth	stator_winding
-0.75214	-1.11845	0.32794	-1.29786	-1.2224282	-0.25018	1.02957	-0.24586	-2.52207	-1.8314217	-2.0661428	-2.0180326
-0.77126	-1.11702	0.32966	-1.29769	-1.2224293	-0.24913	1.02951	-0.24583	-2.52242	-1.8309687	-2.0648587	-2.0176313
-0.78289	-1.11668	0.33277	-1.30182	-1.2224278	-0.24943	1.02945	-0.24582	-2.52267	-1.8304	-2.064073	-2.0173435
-0.78094	-1.11676	0.3337	-1.30185	-1.2224301	-0.24864	1.03284	-0.24695	-2.52164	-1.8303328	-2.0631368	-2.0176322
-0.77404	-1.11678	0.33521	-1.30312	-1.2224286	-0.2487	1.03181	-0.24661	-2.5219	-1.8304977	-2.0627947	-2.0181448
-0.76294	-1.11695	0.3349	-1.30302	-1.2224286	-0.2482	1.03103	-0.24634	-2.5222	-1.8319309	-2.0625494	-2.017884
-0.74923	-1.11617	0.33501	-1.30208	-1.2224296	-0.24791	1.03049	-0.24616	-2.52254	-1.8330117	-2.0621152	-2.0172427
-0.73845	-1.11399	0.33626	-1.30515	-1.2224321	-0.24832	1.03011	-0.24603	-2.52284	-1.8321822	-2.0619526	-2.0172133
-0.73091	-1.11183	0.33491	-1.30379	-1.2224315	-0.24778	1.02985	-0.24598	-2.52281	-1.8315759	-2.062443	-2.0177386
-0.72713	-1.10949	0.33599	-1.30563	-1.2224314	-0.24829	1.02964	-0.24589	-2.52268	-1.8314383	-2.062317	-2.0181801
-0.72371	-1.10828	0.3354	-1.30456	-1.2224283	-0.24791	1.02951	-0.24583	-2.52263	-1.8314928	-2.0620575	-2.0176919
-0.71775	-1.10859	0.33443	-1.30434	-1.2224288	-0.24772	1.02939	-0.2458	-2.52264	-1.8318189	-2.0622487	-2.017435


Motor's parameters

- **ambient:** Ambient temperature as measured by a thermal sensor located closely to the stator.
- **coolant:** Coolant temperature. The motor is water cooled. Measurement is taken at outflow.
- **u_d:** Voltage d-component
- **u_q:** Voltage q-component
- **motor_speed:** Motor speed
- **torque:** Torque induced by current.
- **i_d:** Current d-component

- **i_q**: Current q-component
- **pm**: Permanent Magnet surface temperature representing the rotor temperature. This was measured with an infrared
- **stator_yoke**: Stator yoke temperature measured with a thermal sensor.
- **stator_tooth**: Stator tooth temperature measured with a thermal sensor.
- **stator_winding**: Stator winding temperature measured with a thermal sensor.
- **profile_id**: Each measurement session has a unique ID. Make sure not to try to estimate from one session onto the other as they are


Get test dataset

- Create folder D:\MIB
- Download file [pmsm_temperature_data_test.csv](#)
- Save in D:\MIB









Open Visual Studio / Create C# Console App .NET Core / Name = motor


Create a new project


Search for templates (Alt+S)  [Clear](#)

C# All Platforms Console

Recent project templates

-  Console App (.NET Framework) C# 
-  Windows Forms App (.NET Framework) C#
-  Windows Forms App (.NET Core) C#
-  Class Library (.NET Framework) C#
-  ASP.NET Core Web Application C#

 **Console App (.NET Core)**
A project for creating a command-line application that can run on .NET Core on Windows, Linux and MacOS.
C# Linux macOS Windows Console

 **Console App (.NET Framework)**
A project for creating a command-line application
C# Windows Console

Not finding what you're looking for?
[Install more tools and features](#)

NuGet two packages



Microsoft.Azure.Devices.Client by Microsoft

v1.21.1

Device SDK for Azure IoT Hub



Newtonsoft.Json by James Newton-King

v12.0.2

Json.NET is a popular high-performance JSON framework for .NET

Add class Motor

```
99      public class Motor
100     {
101         public float ambient { get; set; }
102         public float coolant { get; set; }
103         public float u_d { get; set; }
104         public float u_q { get; set; }
105         public float motor_speed { get; set; }
106         public float torque { get; set; }
107         public float i_d { get; set; }
108         public float i_q { get; set; }
109         public float pm { get; set; }
110         public float stator_yoke { get; set; }
111         public float stator_tooth { get; set; }
112         public float stator_winding { get; set; }
113     }
114 }
```

Add namespace

```
6  using Microsoft.Azure.Devices.Client;  
7  using Newtonsoft.Json;  
8  using System;  
9  using System.Text;  
10 using System.IO;  
11 using System.Collections.Generic;
```

Add fields

```
17 private static List<string[]> dataset;  
18 private static int counter = 0;  
19 private static DeviceClient myDevice;  
20 private readonly static string connectionString =  
21     "HostName=loyiothub1.azure-devices.net;DeviceId=loy-iot-  
22     "
```

Add method ReadCSV()

```
37 private static void ReadCSV()  
38 {  
39     using (var reader = new StreamReader(  
40         @"g:\temp\pmsm_temperature_data_test.csv"))  
41     {  
42         dataset = new List<string[]>();  
43         while (!reader.EndOfStream)  
44         {  
45             var line = reader.ReadLine();  
46             var values = line.Split(',');  
47             dataset.Add(values);  
48         }  
49     }  
50 }
```


Add method GetData()

```
51 private static Motor GetData()  
52 {  
53     if (counter++ > 100) counter = 0;    // dataset is 100  
54     var v = dataset[counter];    // get array of one telem  
55     if (v.Length < 12) return null;    // telemerty must ha  
56     Motor myMotor = new Motor();  
57     int i = 0;    // array index  
58     myMotor.ambient = float.Parse(v[i++]);  
59     myMotor.coolant = float.Parse(v[i++]);  
60     myMotor.u_d = float.Parse(v[i++]);  
61     myMotor.u_q = float.Parse(v[i++]);  
62     myMotor.motor_speed = float.Parse(v[i++]);  
63     myMotor.torque = float.Parse(v[i++]);  
64     myMotor.i_d = float.Parse(v[i++]);  
65     myMotor.i_q = float.Parse(v[i++]);  
66     myMotor.pm = float.Parse(v[i++]);  
67     myMotor.stator_yoke = float.Parse(v[i++]);  
68     myMotor.stator_tooth = float.Parse(v[i++]);  
69     myMotor.stator_winding = float.Parse(v[i++]);  
70     return myMotor;  
71 }
```


Add method SendD2C()

```
72 private static async void SendD2C()  
73 {  
74     var motor = GetData();  
75     if (motor == null) return;  
76     var telemetry = new  
77     {  
78         ambient = motor.ambient,  
79         coolant = motor.coolant,  
80         u_d = motor.u_d,  
81         u_q = motor.u_q,  
82         motor_speed = motor.motor_speed,  
83         torque = motor.torque,  
84         i_d = motor.i_d,  
85         i_q = motor.i_q,  
86         pm = motor.pm,  
87         stator_yoke = motor.stator_yoke,  
88         stator_tooth = motor.stator_tooth,  
89         stator_winding = motor.stator_winding  
90     };  
91     var messageString = JsonConvert.SerializeObject(telemetry);  
92     var message = new Message(Encoding.ASCII.GetBytes(messageString));  
93     await myDevice.SendEventAsync(message); // Send the telemetry message  
94     Console.WriteLine("{0} > Sending message: {1}", DateTime.Now, messageString);  
95 }
```

Add code to Main

```
23 private static void Main(string[] args)
24 {
25     ReadCSV(); // read test dataset
26     // Connect to the IoT hub using the MQTT protocol
27     myDevice = DeviceClient.CreateFromConnectionString(
28         connectionString,
29         TransportType.Mqtt);
30     while (true)
31     {
32         Console.WriteLine("Press any key to send a message. Ctrl-C to exit.");
33         Console.ReadLine();
34         SendD2C();
35     }
36 }
```

Run and verify



```
Select D:\_Loy data 2019\_Jobs\20100 Teaching job\40800 MIB\...
Press any key to send a message. Ctrl-C to exit.
10/10/2019 10:08:58 AM > Sending message: {"ambient":"-0.016746586",
"coolant":"1.4801905","u_d":"0.33094862","u_q":"-1.2458229","motor_s
peed":"-1.2224337","torque":"-0.25563973","i_d":"1.0291436","i_q":"-
0.24571528","pm":"0.4530373","stator_yoke":"1.2990731","stator_tooth
":"0.9963015","stator_winding":"0.6344626"}
```

Monitor data in Device Explorer

The screenshot shows the 'Device Explorer Twin' application window with the 'Data' tab selected. The 'Monitoring' section contains the following fields:

- Event Hub: loyiothub1
- Device ID: loy-iot-device-1
- Start Time: 10/10/2019 09:56:37
- Consumer Group: \$Default
- ☐ Enable

At the bottom of the monitoring section are three buttons: Monitor, Cancel, and Clear. To the right of these buttons is a checkbox labeled 'Show :'. Below the monitoring section is the 'Event Hub Data' section, which displays a log of data received from the device:

```
10/10/2019 10:09:00 AM> Device: [loy-iot-device-1], Data:[{"ambient": "-0.016746586", "coolant": "1.4801905", "u_d": "0.33094862", "u_q": "-1.2458229", "motor_speed": "-1.2224337", "torque": "-0.25563973", "i_d": "1.0291436", "i_q": "-0.24571528", "pm": "0.4530373", "stator_yoke": "1.2990731", "stator_tooth": "0.9963015", "stator_winding": "0.6344626"}]
```

Make sure data is right

```
10/10/2019 10:09:00 AM>  
Device: [loy-iot-device-1], Data:[{  
  "ambient":"-0.016746586",  
  "coolant":"1.4801905",  
  "u_d":"0.33094862",  
  "u_q":"-1.2458229",  
  "motor_speed":"-1.2224337",  
  "torque":"-0.25563973",  
  "i_d":"1.0291436",  
  "i_q":"-0.24571528",  
  "pm":"0.4530373",  
  "stator_yoke":"1.2990731",  
  "stator_tooth":"0.9963015",  
  "stator_winding":"0.6344626"}]
```

What's next?

